Zinsser® Deck Bright is a water-based general purpose outdoor cleaner and brightener for timber coated substrates that can be applied to both vertical and horizontal surfaces. Zinsser Deck Bright removes dirt and grime, tree sap, food stains, oil, mildew and mild oxidation of raw timber. Excellent for cleaning oil and grease from BBO's and concrete. Zinsser Deck Bright can be applied to Zinsser® Timber & Decking Finish coatings, and other surface coatings, as often as required to maintain a fresh clean look.

READ ALL DIRECTIONS BEFORE BEGINNING PROJECT

RECOMMENDED FOR: Exterior timber surfaces.

NOT RECOMMENDED FOR: Interior floors or furniture.

APPLICATION TIPS: For best results, apply in temperatures between 23°C and 27°C. Do not apply if humidity is greater than 85% or temperature is below 5°C.

PRODUCT PREPARATION:

EXTREME SURFACE CONDITION - For severe dirt and grime, tree sap build up, accumulated BBQ stains and mild oxidation of raw timber. Application Ratio: Dilute one (1) part Zinsser Deck Bright to four (4) parts cold water by

MODERATE SURFACE CONDITION - Dirt and grime, fresh BBQ stains, light build up of tree sap and light oxidisation of raw timber. Application Ratio: Dilute one (1) part Zinsser Deck Bright to eight (8) parts cold water by volume.



RUST-OLEUM AUSTRALIA PTY. LTD. Unit 12, 4 Southridge Street Eastem Creek, NSW 2766 Australia PH: 1:300 784 476 www.rustoleum.com.au sales@rustoleum.com.au HAYDN BRUSH CO. LTD. PO Box 86054 Christchurch 7675 NZ PH: 64 3 347 7770 www.rustoleum.co.nz info@haydn.co.nz

©2018 Rust-Oleum Corporation Made in Australia 0118

LIGHT SURFACE CONDITION - General Cleaning and upkeep. Application Ratio: Dilute one (1) part Zinsser Deck Bright with ten (10) parts cold water by volume.

APPLICATION: Pre-wet the surface with water and apply the mixed Zinsser Deck Bright by mop or pressure spary and allow soaking for a minimum of 2-3 minutes. For stubborn stains, allow 5-10 minutes. Scrub surface with a stiff bristle broom and rinse off with clean water at low pressure from a garden hose or pressure washer, using a fine tip with 1800 PSI

MAINTENANCE: It is recommended that coated timber surfaces be cleaned with Zinsser Deck Bright at least every 3 to 6 months depending on location/ density of surrounding trees and native wildlife. For areas exposed to heavy soiling, frequency of cleaning will need to be at shorter intervals to maintain a natural looking substrate.

COVERAGE: Approximately 10m2 per litre when diluted.

CLEAN UP: Use soap and water for clean-up.

STORAGE: Store in a cool, dry place.



POISON KEEP OUT OF REACH OF CHILDREN DO NOT SWALLOW

SAFETY DIRECTIONS: If medical advice is needed, have product container or label at hand. Keep out of reach of children. Read label before use. Use only outdoors or in a well-ventilated area. Do not eat, drink or smoke when using this product. Wear protective gloves and clothing eye protection/face protection. Avoid contact with skin and eyes. Wash hands after use. Keep containers sealed when not in use. Avoid release to the environment.

WARNING STATEMENTS: Harmful if swallowed or inhaled. Skin and eye irritant.

FIRST AID INSTRUCTIONS

FSWALLOWED: Immediately call a POISON CENTRE (Phone: AUX 13 11 26; NZ 0800 764 766) or doctor. Do NOT induce vomiting. IF INHALED: Remove affected person to fresh air and keep at rest in a position comfortable for breathing. IF IN EYES: Flush eyes with water for 15 minutes. If irritation persists, call a doctor. IF ON SKIN (or hair): Remove immediately all contaminated clothing. Rimes skin water shower. Wash contaminated clothing before reuse. If skin irritation or a rash occurs: Get medical advice/attention. IN CASE OF FIRE. Use alcohol resistant foam for extinction. IF exposed or concerned: Get medical advice.

For further information refer to the Safety Data Sheet available at www.rustoleum.com.au or www.rustoleum.co.nz.

