TECHNICAL DATA

BEN-02

Benchtop Transformations⁻ **RUST-0 TRANS**

RUST-OLEUM[®] BENCHTOP TRANSFORMATIONS TINT BASE

DESCRIPTION AND USES

Rust-Oleum[®] Benchtop Transformations is a do-it-yourself coating system that enables you to easily transform outdated, worn or damaged benchtops into a beautiful and durable gloss finish. It is great for kitchen benchtops, bathroom benchtops, bars and tables.

PRODUCTS

SKU	DESCRIPTION	
314307	Light Tint Base Kit	
315027	Dark Tint Base Kit	

KIT CONTENTS

- 946mL Base Coat Tint Base*
- 237 mL Protective Top Coat Part A
- 237 mL Protective Top Coat Part B
- Diamond-Embedded Sanding Tool
- 150mm x 10mm Nap Roller
- 150mm x 6mm Velour Roller
- Scrub Pad
- Stir Sticks
- Instructional Booklet
- Instructional DVD

*IMPORTANT: Base Coat must be tinted in store and used within 7 days of tinting

SUPPLIES NEEDED

- (2) Mini Roller Paint Trays
- 150mm Roller Frame
- (2) 50mm Synthetic Paint Brushes
- 50mm Smooth Painter's Tape
- Drop Cloths
- Lint-Free Cloths/Rags
- Disposable Gloves
- Protective Glasses
- Dust Mask

SUGGESTED ITEMS NEEDED

- Rust-Oleum[®] Zinsser
- 100% Silicone Kitchen and Bath Caulk (for repair)
- Hand Brush and Dust Pan or Shop Vacuum with Brush Attachment
- Putty Knife

COVERAGE

Each kit covers 4.6 square meters

PRODUCT APPLICATION

Watch the entire instructional DVD and use the printed instructions for the complete, step by step, procedure on application of the materials.

SURFACE PREPARATION

Mask off the sink, appliances, and all adjacent areas with smooth painter's tape. Spread the drop cloth on the floor of all base cabinets. Apply smooth painter's tape on the wall behind the backsplash.

The surface of the benchtop must be completely cleaned and de-glossed in accordance to the instructions to ensure proper performance of the Benchtop Transformations. Complete de-glossing is CRITICAL for proper coating system performance. For proper adhesion, prime bare timber with Rust-Oleum[®] Zinsser BIN Primer.

APPLICATION OF BASE COAT

Apply when air (ambient) and surface temperature is 16-29°C and the relative humidity is below 85%.

Thoroughly stir the Base Coat using a stir stick. Pour a portion of the Base Coat into a clean paint tray. Starting with the back splash, use a 50mm synthetic brush to apply an even coat of Base Coat. Be sure that the coverage includes 2-5cm of the flat benchtop surface that connects to the backsplash. This will prevent the roller from accidentally bumping into the backsplash while rolling. Working from back-to-front, use the enclosed 150mm x 10mm nap roller to apply an even coat of Base Coat over the entire benchtop. Then use the brush again to coat any tight spaces (i.e. around the sink or in the corners).

For each section, after the Base Coat has been applied to the entire surface, re-roll in one, uniform direction towards the front (your body). After the Base Coat has been applied, quickly inspect the entire benchtop for sags, mistakes or areas of thin coverage. Apply more Base Coat where necessary. After the first coat has dried for at least 30 minutes or until the inside edges are dry, apply a second coat as detailed above. Once the second coat is dry to touch (approximately 30 minutes) and before it completely dries, be sure to remove any tape by first scoring around the edges. Allow the coating to dry overnight. Apply the Protective Topcoat within 24 hours of applying the Base Coat.

TECHNICAL DATA

RUST-OLEUM[®] BENCHTOP TRANSFORMATIONS TINT BASE

PRODUCT APPLICATION (cont.)

Transformations[.]

APPLICATION OF THE TOPCOAT

Benchtop

Wipe down the benchtop with a damp lint-free cloth to remove any dust that may have settled overnight and allow to dry.

Wearing gloves and safety glasses pour the entire contents of Part A Activator into the Part B Base and thoroughly mix with a stir stick for at least 2 minutes. It is important to stir thoroughly for proper activation. Then pour a portion of the blended Protective Topcoat mixture into a clean paint tray and cover the remaining paint.

IMPORTANT: Once mixed and activated, the working time is 90 minutes. Do not use leftover Protective Topcoat after 90 minutes even if it appears liquid.

Use a clean 50mm synthetic paint brush to apply an even layer of Protective Topcoat to the backsplash and along the edges. Even out the decorative mica flakes as you brush so they are evenly dispersed. Be sure that the coverage includes 2-5cm of the flat benchtop surface that connects to the backsplash as when the Base Coat was applied. This will prevent the roller from accidently bumping into the backsplash when rolling.

PRODUCT APPLICATION (cont.)

APPLICATION OF THE TOPCOAT (cont.)

For even coverage and to avoid brush marks, the 150mm x 6mm velour roller that is provided must be used. Roll an even coat, from back to front, over the entire surface of the benchtop and over the front edge. Again blend the decorative mica flakes with the roller so they are evenly dispersed.

For each section, once the protective Topcoat has been applied to the entire surface, re-roll in one uniform direction. Allow the Protective Topcoat to dry undisturbed, taking steps to make sure the benchtop is not touched or brushed up against. Keep windows closed, pets away, and ceiling fans off. The Protective Top Coat will be tack free in 4-6 hours. Coating will dry overnight.

Allow the benchtop to dry to the touch, approximately 4-6 hours. Score the smooth painter's tape along the edges of the benchtop. Then carefully remove the tape. Allow the Protective Topcoat to dry 48 hours for light use. Wait 7 days for full cure and maximum stain resistance.

TECHNICAL DATA

BEN-02

Benchtop Transformations[.]

RUST-OLEUM[®] BENCHTOP TRANSFORMATIONS TINT BASE

PHYSICAL PROPERTIES

		BENCHTOP TRANSFORMATIONS TINT BASE		
		BASE COAT	TOP COAT	
Resin Type		Acrylic	Epoxy Silicone Amine	
Pigment Type		Titanium Dioxide	None	
Weight	Per Liter	1.16-1.24kg	1.09kg/l	
Solids	By Weight	56.2%	73.9-74.0%	
	By Volume	41.1%	64.6-64.8%	
Mixing Ration		NA	1:1 by volume	
Volatile Organic Compounds		75g/l	<300g/l	
Recommended Dry File Thickness (DFT) per Coat		1.5-2mils	2-2.5mils	
Wet Film to Achieve DFT (Unthinned material)		3.5–5mils	3-3.5mils	
Practical Coverage at Recommended DFT (assume 15% material loss)		280–375 sq.ft./gal 6.9-9.2 m ² /l	45-55 sq.ft./pint 4.2-5.1 m ² /pint	
Dry Times at 25°C and 50% Relative Humidity	Touch	30 minutes	12 hours	
	Recoat	60 minutes	24 hours	
	Full Cure	7 days	7 days	
Shelf Life		5 years	2 years	
Flash Point		>93°C	Part A 71°C, Part B 39°C	
Safety Information		For additional information, see SDS		

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.



Rust-Oleum Australia PTY. LTD. Unit 12, 4 Southridge Street Eastern Creek, NSW 2766 Australia PH: 1 300 784 476 www.rustoleum.com.au email: sales@rustoleum.com.au HAYDN BRUSH CO. LTD. PO Box 86054 Christchurch, 7675 New Zealand PH: 64 3 347 7770 www.rustoleum.co.nz Email: info@haydn.co.nz